

**Home  
Sight™**



LTE Connectivity

LTE200

Quick Start Guide

## About

Your HomeSight™ LTE200 provides 4G LTE data connectivity to supported USB-C connected devices. The LTE connection can be your primary data connection to the Internet or as a backup to your existing Internet connection.

## In the box



LTE200




USB-C cable

Note: Micro SIM card is not included in the box.

## Overview

### Top view



Top cover

## Rear view



## LED descriptions


LED	Status
TO DEVICE	<ul style="list-style-type: none"><li>• <b>Solid Green:</b> When connected to your supported USB-C device and power supply is connected to the power outlet.</li><li>• <b>Off:</b> Not connected to your supported USB-C device.</li></ul>
LTE	<ul style="list-style-type: none"><li>• <b>Solid Green:</b> LTE connection is established.</li><li>• <b>Blinking Green</b> (continuously): The SIM card is not inserted correctly or the SIM card is not activated.</li></ul>

## Inserting the SIM card

1. Press and then slide in the direction shown here to open the top cover of your LTE200.



2. Insert the micro-SIM card into the SIM slot as shown here.




3. After you have inserted the micro-SIM card, slide back to close the top cover.

# Installing your LTE200

1



2



## Need help?

For further help or support, you can visit our website:

<https://support.homesight.care>

OR scan the QR code.



### **IMPORTANT SAFETY INSTRUCTIONS**

Never place the product on top of or close to any heat sources such as other electronic devices. Doing so will reduce life time and may cause irreparable damage or malfunction. Do not use the product near water. Note that the ambient temperature must be below 104° F/40° C. Be sure to maintain necessary space around the product to allow for proper ventilation. Never use the product outside. This is a Class II product.

### **CANADIAN COMPLIANCE**

This Class B digital apparatus meets all requirements of the Canadian Interference Causing Equipment Regulations and CAN ICES-003 (B)/NMB-003(B).

This device complies with Innovation, Science and Economic Development Canada's license-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

### **RADIATION EXPOSURE STATEMENT**

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

## **FEDERAL COMMUNICATION COMMISSION INTERFERENCE STATEMENT**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Increase the separation between the equipment and receiver.
- Reorient or relocate the receiving antenna
- Connect the equipment into an outlet on a circuit different from that the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**FCC CAUTION:** Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

**RADIATION EXPOSURE STATEMENT:** This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

## **EUROPEAN UNION (EU) COMPLIANCE AND MANUFACTURER CONTACT ADDRESS**

EU Compliance is maintained at the following address: ARRIS Netherlands B.V.  
Hoogoordreef 5, 1101 BA Amsterdam, The Netherlands.

## UNITED KINGDOM (UK) COMPLIANCE AND MANUFACTURER CONTACT ADDRESS

UK Compliance is maintained at the following address: ARRIS Global Limited, Victoria Road, Saltaire, West Yorkshire, BD18 3LF, United Kingdom.

<b>Ambient operating temperature</b>	32-104°F / 0-40°C at 5-95% non condensing humidity.
<b>Voltage</b>	12Vdc, 1.67A
<b>Power consumption</b>	20W
<b>Power supply unit</b>	This product is intended to be supplied with a UL-listed power adapter, rated 5V, 3A min. or 12Vdc, 1.67A min., and Tma 40°C (min.), class II type and compliance with PS2 or LPS. Approved for use up to 2438m.

### Caring for the Environment by Recycling



When you see this symbol on an ARRIS product, do not dispose of the product with residential or commercial waste. Some countries or regions have set up systems to collect and recycle electrical and electronic waste items.



Recycling information can be obtained from the WEEE recycling section at [www.commscope.com](http://www.commscope.com). Please recycle product packaging and this document.